



NOTES:

- 1. TOOLED CONTRACTION JOINTS SHALL BE EVENLY SPACED BETWEEN 5' AND 10' APART OR AS DIRECTED BY TOWN ENGINEER.
- 2. EXPANSION JOINTS SHALL BE SPACED EVERY 200' MINIMUM AND AT THE FOLLOWING LOCATIONS:
 - A) AT BOTH EDGES OF A DRIVEWAY
 - B) BETWEEN THE BACK OF SIDEWALK AND DRIVEWAY
 - C) BETWEEN EXISTING CONCRETE AND A NEW CONCRETE POUROR AS DIRECTED BY THE TOWN ENGINEER.
- 3. EXPANSION JOINTS SHALL BE IN PLACE PRIOR TO PLACING THE CONCRETE.
- 4. SIDEWALK CROSS SLOPE SHALL NOT EXCEED 2%.

DETACHED SIDEWALK DETAIL
NTS

