



NOTE:  
 1. BOND WIRES SHALL BE ATTACHED TO THE PIPE, VALVE OR FITTING TOP CENTERLINE.

## JOINT BOND INSTALLATION

NTS

