



DO NOT CUT OR DAMAGE LEADER, PRUNE DAMAGED OR DEAD BRANCHES AFTER PLANTING AND STAKING. PRUNE TO TYPICAL FORM OF SPECIES. DO NOT PRUNE UP LOWER BRANCHES.

SPECIFIED HEAVY DUTY TRUNK COLLAR ATTACHMENT. DO NOT TWIST.

14 GAUGE GALV. WIRE WITH 1/2" DIA. X 36" WHITE PVC PIPE ON ALL GUY WIRES. KEEP GUY WIRES CLEAR OF BRANCHES TO PREVENT RUB DAMAGE.

ROOT FLARE TO BE AT OR SLIGHTLY ABOVE THE FINISHED GRADE. SET TRUNK PLUMB. SEE NOTES AND SPECIFICATIONS IN SECTION 1500.

APPLY SPECIFIED MULCH AT 0" DEPTH AT TRUNK AND 4" DEPTH AT EDGE OF RING, INSIDE 4" WATERING SAUCER. REMOVE SAUCER UPON SODDING/ SEEDING IN IRRIGATED AREAS.

(3) SPECIFIED STAKES AT 4" WATERING SAUCER. DRIVE 24" INTO UNDISTURBED SUBGRADE. AND THE TOP SHALL BE FLUSH WITH GRADE. REMOVE SAUCER UPON SEEDING OR SODDING IN IRRIGATED AREAS. CONNECT GUY TO STAKE AT TOP 1" OF STAKE.

4" HIGH WATER SAUCER TO BE OUTSIDE OF DRIP LINE OF EVERGREEN TREES.

REMOVE AND REPLACE EXISTING SOIL WITH BACKFILL MIXTURE AS PER SPECIFICATIONS. 12" WIDE X 12" DEPTH.

MACHINE DUG ROOTBALL IN MACHINE DUG HOLE. DO NOT USE TWINE, WIRE, OR BURLAP ON MACHINE DUG PLANTS.

**NOTES**

1. WHEN DIGGING HOLE WITH SPADE, THE DEPTH OF THE HOLE MUST CONFORM TO DEPTH REQUIRED FOR THE ROOT FLARE TO BE FLUSH WITH GRADE.
2. GUYING AND STAKING TO BE REMOVED AFTER ONE GROWING SEASON.
3. DO NOT PLANT ANY PLANT WITH A ROOTBALL THAT IS NOT IN COMPLIANCE WITH THE COLORADO NURSERY ACT REQUIREMENTS.

**EVERGREEN TREE PLANTING**  
NTS



TOWN OF FREDERICK  
STANDARDS & SPECIFICATIONS